

System Startup

To start-up the classroom technology, touch the panel or "Press Here to Continue". This will lower the screen, turn on the projector, and switch to the Podium PC. (if the screen is blank, just tap on the keyboard to wake-up the pc.)

General Classroom Control



Projector Image Mute

Press "Image Mute" to stop showing the projected image. Press "Image Mute" again to show the image.

Confidence Monitor Control

Power "On" or power "Off" controls the image display to the Confidence Monitor, mounted on the rear or side wall of the classroom.

Audio Control

To control the sound volume of the classroom's speaker, press the up arrow to raise and the down arrow to lower the volume. The color bar on the right will display the current level. In addition, a Mute button is provided to turn off or on the sound. If no sound is heard, also check the Podium PC/laptop/tablet sound output level.

System Shut Down

To turn off the classroom technology, press the "System Off" button and then press the "Yes, Power down and exit" button. This will turn off everything except the podium pc.



For Assistance Call User Support Services at X3500

System Startup

To start-up the classroom technology, touch the panel or "Press Here to Continue". This will lower the screen, turn on the projector, and switch to the Podium PC. (if the screen is blank, just tap on the keyboard to wake-up the pc.)

General Classroom Control



Projector Image Mute

Press "Image Mute" to stop showing the projected image. Press "Image Mute" again to show the image.

Confidence Monitor Control


Power "On" or power "Off" controls the image display to the Confidence Monitor, mounted on the rear or side wall of the classroom.

Audio Control

To control the sound volume of the classroom's speaker, press the up arrow to raise and the down arrow to lower the volume. The color bar on the right will display the current level. In addition, a Mute button is provided to turn off or on the sound. If no sound is heard, also check the Podium PC/laptop/tablet sound output level.

System Shut Down

To turn off the classroom technology, press the "System Off" button and then press the "Yes, Power down and exit" button. This will turn off everything except the podium pc.



For Assistance Call User Support Services at X3500